

Fangor **CD/DVD PLAYER** w/ Bluetooth & Built in Speaker

PLEASE RETURN AT THE ADULT REFERENCE DESK

CD/DVD PLAYER w/ Bluetooth & Build-in Speaker



Circulation	3 weeks
Renewals	1x
Overdue fines	\$10

CONTENT		FEE
Fangor 7 in 1 multi-functional CD/DVD player with bluetooth & built in speaker w/ dust cover		\$65
Carrying case	ANICK	\$15
HDMI Cable		\$10
AV Cable	111) 111) 111)	\$10
USB Adapter	=	\$10
Remote Control		\$15
Desk Stand		\$10
User manual	TO CONTROL	



QUICK GUIDE

CD/DVD PLAYER with bluetooth & build-in speaker

Fangor YR-Q100



Power on/off

Connect the power cable with adapter and insert into power outlet. Pull-Switch: Pull the power cable to power on/off. The LED Screen will light up in blue. Pull the power cable again to turn it off.




Play Discs

First open the dust cover and remove the protect paper. Then place a disc on the player and put the cover back. The CD will automatically start to rotate and play. *Note: make sure the LED Screen is on Disc Mode. (Switch by pressing MODE. To STOP also switch MODE or press Play/Pause on remote control). If the dust cover isn't in place, it won't play.


Caution:
Please place the protect
paper back after the use.

Connect to TV




1. AV Port

If your TV has a AV port, please use the supplied AV cable to connect, and switch your TV to AV mode after connected. Place a DVD instead of CD for video playback.




2. HDMI Port

High resolution output.





Turn this player into mini boombox by pressing MODE to switch to Bluetooth mode. Then activate Bluetooth in your mobile phone/device, and choose "YR-Q100" to pair. Playing music on your phone/device and the audio will transmitted to the Player speaker through Bluetooth



Other advanced features please refer to User Manual



7 IN 1 FUNCTION

1. CD Player

2. HD DVD Player

3. Bluetooth Speaker

4. FM Radio

5. Mini Boombox

6. USB Flash Drive Player

7. Alarm Clock